

E-line Important Notes

- .1 Load and unload from the loadlock only. Do not open the chamber

- .2 WD should be sample thickness + 9mm.

- .3 To restart the SmartSEM program you must restart the E-line program. You cannot open SmartSEM independently

- .4 Ensure transfer rod is completely pulled out before opening the loadlock door

- .5 Open/close loadlock door by holding the door, not the transfer rod